



Important Note: Cut out templates and tape to **bottom** of the black plastic wings.
 Drill two 1/2" positioning holes through the **bottom surface only**.
Enlarge to final size after checking test fit and centering.

